

Repkord

STAGE 3 - Top Assembly

Written By: Pooch



Step 1 — Parts and Pieces



- Insert wisdom here.

Step 2 — Parts and Pieces



- Top hinge clamp plate
- 16mm bolts, M3 Nylocks
- Top Panel

Step 3 — Attaching the Vinyl Hinge to Top Panel



- Stand the top panel on end so the holes are at the top closest to you
- Press three 16mm bolts in the middle 3 holes so that the ends of the bolts protrude from the unfinished side of the panel as pictured.

⚠ DO NOT do the outside two holes right now. They will be done in a later step.

- Make sure you have removed the vinyl cutouts from the hinge prior to assembling as outlined in STEP 0
- The hinge holes will only line up on one side so find the side with matching holes and press the vinyl hinge onto the exposed bolts. Do this while the panel is standing up so the bolts don't fall out on you. The vinyl will hold them in once pressed on so you may lay the panel flat again with the unfinished side up.
- Place the clamp bar over top the exposed bolts so that its edge and the edge of the top panel line up evenly.
- Time to move on to STAGE 4